# Minx Xi IR Remote Control Codes

System Code = 27     (RC-5 Code)

| Key | Command code dec. |
| --- | --- |
| Memory | 88 |
| Standby Toggle | 2 |
| Power on | 102 |
| Power off | 103 |
| Brightness | 51 |
| Reply | 9 |
| Random | 20 |
| Repeat | 21 |
| Info | 28 |
| Mute On | 126 |
| Mute Off | 127 |
| Home | 12 |
| Up | 13 |
| Return | 22 |
| Skip Back | 23 |
| Left | 16 |
| Select | 17 |
| Right | 18 |
| Skip Forward | 25 |
| Stop/Cancel | 27 |
| Down | 19 |
| Play/Pause | 24 |
| MP3 | 32 |
| A1 | 33 |
| A2 | 34 |
| Bluetooth | 31 |
| D1 | 35 |
| D2 | 36 |

System Code = 17     (RC-5 Code)

| Key | Command code dec. |
| --- | --- |
| Internet Radio | 111 |
| Services | 114 |
| Media | 112 |
| Podcasts | 115 |
| Tone/Balance | 123 |
| Mute Toggle | 67 |
| Volume Up | 64 |
| Volume Down | 65 |